



DIY underbed Shoe Storage

By **Anika's DIY Life**

Difficulty

Moderate

Build a simple under bed show storage with storage. It has a plexiglass cover so you can see inside and moveable dividers to keep the shows organized.



Tools

Kreg Tools

Wood
Project [Wood Project Clamp - 6"](#)
Clamp -
6

Kreg®
Pocket-
Hole Jig [Kreg® Pocket-Hole Jig 720](#)
720

Other Tools

Circular Saw (corded)

Miter Saw

Drill (cordless)

Shop Vacuum

Workbench

Materials

Wood Products

- 1** Plywood , 3/4" Thick , Half Sheet
- 2** Board , 1x6 , 96"
- 4** Board , 1x4 , 96"

Hardware & Supplies

- 1** Plexiglass (3' X 3')
- 4** Casters
- 2** Hinges
- 1** Cabinet Pull
- 36** 1 1/4" Pocket Holde Screws
- 20** 3/4" Wood Screws

Cut List & Parts

- 1 Base Plywood , 3/4" X 29 3/4" X 33 3/4"
- 2 Box Sides (Long) , 1" X 6" X 33 3/4"
- 2 Box Sides (Short) , 1" X 6" X 31 3/4"
- 2 Lid Side (Long) , 1" X 4" X 31 1/4"
- 2 Lid Side (Short) , 1" X 4" X 30 1/4"
- 1 Long Center Divider , 1" X 4" X 33 3/4"
- 4 Short Dividers , 1" X 4" X 29 3/4"
- 1 Plexiglass , 29 1/4" X 33 1/4"


Directions

1

Build the box

Assemble the box for the shoe organizer using the $\frac{3}{4}$ " base plywood and the 1" x 6" sides. The pocket holes are all around the underside of the plywood as shown in the schematic.


Join using $1\frac{1}{4}$ " pocket hole screws and wood glue. Ensure everything is square.



2


Build the box- 2

Also add pocket hole screws to the insides of the opposite sides as show in the schematic.



3**Build frame for Lid**

Build a frame for the lid using the 1x4 boards using 1 1/4" pocket hole screws and wood glue. Ensure everything is square.




4

Attach plexiglass

Attach plexiglass to the inside of the lid using 3/4" wood screws.

To do this - pre-drill holes slowly in the plexiglass and then add screws. Be careful not to over tighten.

Note - you can also route out the insides of the lid before building the frame to inset the plexiglas.. I wanted to keep this a simple build that didn't involve a lot of tools.




5

Cut dividers

Cut up the 1" x 4" dividers for the organizer as shown in the picture. This gives a 10 shoe organizer. You can add extra slits in the long divider to add more options for the arrangement.

The dividers fit snug and hence are not attached to the box.




6

Finishing touches

Sand and stain or paint per your choice.

Attach the lid to the box using hinges.

Add casters on the bottom and a pull to the front of the box.



7

See more information

For more details on this project, please see - <https://www.anikasdiylife.com/diy-under-bed-shoe-organizer/>

Video tutorial at - <https://youtu.be/OIGCQN-VmmE>