

Fluted Sofa Table

By **Built by Bec Designs**

Difficulty

Moderate

Build this style sofa table or use it as a console table!



Tools

Kreg Tools

- Kreg®
Pocket-Hole Jig 720PRO
[Kreg® Pocket-Hole Jig 720PRO](#)
- Zinc
Pocket-Hole Screws
[Zinc Pocket-Hole Screws](#)
- Zinc
Pocket-Hole Screws
[Zinc Pocket-Hole Screws](#)

Other Tools

- Router
- Miter saw
- Sander
- Drill
- Clamp
- Roundover bit
- Track saw
- Table saw

Materials

Wood Products

- 2 Wood , 1x6x8'
- 2 Wood , 1x8x6'
- 1 Wood , 2x6x6'
- 75 Dowel , 1/4"

Hardware & Supplies

- 25 1 1/4" Pocket Hole Screws
- 25 3/4" Pocket Hole Screws
- Variation Of 80,120, 150 And 220 Sandpaper
- Wood Glue
- Stain Of Choice
- CA Glue
- Z Clips/Figure 8 Fasteners

Cut List & Parts


- 2 Top , 3/4" X 7.25" X 71"
- 2 Long Apron , 3/4" X 5.5" X 66"
- 2 Short Apron , 3/4" X 5.5" X 10.5"
- 75 Dowels , 1/4" X 5.5"
- 4 Legs , 1.5" X 1.5" X 26"

Directions

1

1

Cut wood to size. Set your pocket hole jig to 3/4" and pocket hole the top boards together using 3/4" wood glue and 3/4" screws.



2

2

Cut the legs using a track saw or table saw.

Optional: Taper the legs at 5" from the bottom. Taper should be from 1.5" - 1".

3**3**

Cut the apron pieces to size. Using 1 1/4" pocket hole screws, first attach the short springs to the legs and then the long aprons. Make sure to recess the apron 1/4" to make room for the dowels.



4

4

Optional: roundover the legs using a router.

5**5**

Cut all the dowels to size. Attach to the aprons using clear CA glue.



6**6**

Sand the top and base then stain your choice of color.



7**7**

Attach the top to the base using Z clips or figure 8 fasteners.

8**8**

Optional: add hardware
