

Boot Tray Cover

By **Jill Approved**

Difficulty

Easy

It's time for those wet, snowy boots to be drying in the mudroom. This boot tray cover will help corral all the puddles while looking pretty in your entry.



Tools

Kreg Tools



Other Tools

Miter Saw

Drill (cordless)

Sander

Materials

Wood Products

- 1 Board , 1x3 , 72"
- 2 Board , 1x2 , 96"
- 1 Board , 1x2 , 72"

Hardware & Supplies

- 1 Pack Of 50- 1 1/4" Pocket Screws

Cut List & Parts

- 2 Sides , 1x3 @ 32"
- 2 Sides , 1x3 @ 16"
- 13 Slats , 1x2 @ 16"

Directions

1

Create the Sides

Attach the two 1x3 sides @ 32" to the two 1x3 sides @ 16" using 1 1/4" Kreg screws.

Please note that these measurements were all created to fit the standard boot tray I have. You may need to alter the measurements to suit yours.



© Jillian Grennon

2**Prepare Slats**

Cut all 13 1x2 slats down to 16" and add 2 pocket holes on each end.



3

Measure Your Boot Tray

All of the instructions for this boot tray cover are made and measured to suit my standard boot tray which is 29 3/4" x 14 3/4".

Please note you may need to alter the measurements to suit your project.



© Jillian Grennon

4**Attach Slats**

Attach each slat with 1 1/4" pocket screws. Use a scrap piece of 1x2 to space the 13 slats evenly.



5**Finish as Desired**

Due to wet shoes frequently landing on this wood, you will want to treat it with polyurethane for protection.



6

Admire the Beauty

Something about all those evenly spaced lines is beautiful, isn't it? :)



© Jillian Grennon