

Modular Kitchen Storage

By **Sawdust 2 Stitches**

Difficulty

Easy

A great compromise of form and function. This Pottery Barn inspired cubby organizer is part of a modular set that can be used in combination with other modular pieces (see image 2), or it can be used alone!



Tools

Other Tools

- Miter Saw
- Tape Measure
- Drill (cordless)
- Nail Gun
- Sander

Materials

Wood Products

- 2 Board , 1x6 , 96"
- 1 Board , 1x2 , 96"

Hardware & Supplies

- 1 2" 16 Gauge Nails
- 1 Wood Glue
- 2 Mounting Brackets
- 1 Desired Paint And/Or Stain

Cut List & Parts


- 2 Side Frame , 3/4" X 5 1/2" X 25 1/2"
- 2 Top And Bottom Frame , 3/4"x 5 1/2 " X 24"
- 3 Shelves , 3/4" X 5 1/2" X 11 3/4"
- 1 Shelf Divider , 3/4" X 5 1/2" X 7 1/2"
- 2 Front Rails , 3/4" X 1 1/2" X 25 1/2"
- 1 Back Support , 3/4" X 1 1/2" X 24"

Directions

1

Assemble Frame


Join both 25 1/2" and 24" 1x6" boards using wood glue and 2 inch, 16 gauge finishing nails. This will form a 25 1/2" square.



Sawdust²Stitches

2**Vertical Divider**


Insert remaining 1"x 6"x 24" board centered vertically. Glue and secure using 2" 18 gauge finish nails.



Sawdust²Stitches

3**Shelf Insert**

Using (2) of the 1"x 6"x 11 3/4" boards and the 1"x 6"x 7 1/2" board, and form a "I". Make sure that the 7 1/2" board is centered on both 11 3/4" boards. Use wood glue and reinforce with 2" 16 gauge finish nails.




Sawdust & Stitches

4

Shelves

Insert the pre-assembled "I" shelf so that the base of the bottom board is 17" from the top of the unit.


On the right hand side, insert the remaining 1"x 6"x 11 3/4" board. Position it so that the bottom of the board is 13" from the top of the unit.



Sawdust & Stitches

5**Front Rails**


Attach the 25 1/2" 1x2" board(s) to the face of the unit using wood glue and 2 inch 16 gauge finishing nails.



Sawdust²Stitches

6**Back Support**

Attach the remaining 24" 1x2" board using wood glue and 2 inch 16 gauge finishing nails. This is an ideal place to attach the unit to the wall, or you can attach hanging hardware to the back.



SawdustStitches

7**Finish**

Fill all nail holes with wood filler. Sand smooth, then apply desire stain and/or paint.