


Custom Lighted Address Plaque

Difficulty

Easy

Give a distinctive look to your home by building and installing your own custom house numbers sign. It even features lights to illuminate your address at night. And the lights are solar, so there's no wiring involved. All you have to do is screw the lights to your sign.



Tools

Kreg Tools

Kreg®
Pocket-
Hole Jig
720

[Kreg® Pocket-Hole Jig 720](#)

Other Tools

Jigsaw

Miter Saw

Square

Tape Measure

Drill (cordless)

Sander

Materials

Wood Products


- 3** Board , 1x2 , 48"
- 1** Board , 1x4 , 48"
- 1** Board , 1x6 , 48"

Hardware & Supplies

- 1** Pair Of Solar Railing Lights
- 9** 1 1/2" Exterior Pocket-hole Screw
- 14** 1 1/2" Flat-head Exterior Wood Screw
- 1** Waterproof Exterior Wood Glue
- 1** Hangman Hanging System, 6"

Cut List & Parts


- 1 Cap , 7/8" X 3 1/2" X 22" Cedar
- 1 Long Cap Trim , 7/8" X 1 1/2" X 23 3/4" Cedar
- 2 Short Cap Trim , 7/8" X 1 1/2" X 3 1/2" Cedar
- 1 Sign Back , 7/8" X 5 1/2" X 23 3/4" Cedar
- 2 Sign Trim , 7/8" X 1 1/2" X 23 3/4" Cedar
- 2 Vertical Cleat , 7/8" X 1 1/2" X 8 1/2" Cedar
- 1 Hanger Cleat , 7/8" X 1 1/2" X 8" Cedar
- 1 Hanger Spacer , 7/8" X 1 1/2" X 1 1/8" Cedar



3

Add the Cap Trim


Cut one Long Cap Trim and two Short Cap Trim boards to length from 1x2 cedar, as shown in the cutting diagram. Use spacers to help position the cap, as shown. Then spread waterproof exterior wood glue on the ends and front edge of the Cap. Position the Short Cap Trim at each end, and attach it using 1 1/2" exterior pocket-hole screws. Then position the Long Cap Trim, and attach it in the same way.



4

Make the Cleats


Cut two Vertical Cleats to length from 1x2 cedar, as shown in the cutting diagram. On each Vertical Cleat, cut or sand a 1/4" chamfer the ends, as shown. Next, drill six 3/16" holes at the locations shown. Now cut a Hanger Cleat from 1x2 cedar and drill two 3/16" holes at the locations shown.



5

Assemble the Sign Back


Cut a two pieces of Sign Trim to length from 1x2 cedar, and one Sign Back from 1x6 cedar, as shown in the cutting diagram. Lay Sign Back and Sign Trim boards smooth side down on a work surface. Create gaps between the boards using 1/4" spacers. And make sure the ends of the boards are even. Then position the two Vertical Cleats, and attach them as shown using glue and 1 1/2" exterior flat-head wood screws. Add the Hanger Cleat to the Sign Back with two 1 1/2" exterior flat-head wood screws. Finally, cut the small Hanger Spacer from 1x2 cedar, and then secure it to the back of the Sign Trim Board with glue. This spacer will help the sign hang straight when it's installed on your house.



6

Attach the Cap to the Back

Flip the sign back assembly over onto the cleats, position and cap assembly on the back assembly where shown, and then secure the cap assembly using glue and 1 1/2" exterior flat-head wood screws.



7**Sand and Apply a Finish**

With the sign parts assembled, you can sand the exposed surfaces as needed using 150-grit sandpaper. We then applied a couple of coats of a clear exterior oil finish to protect and add beauty to the cedar. If you prefer, you can use an exterior stain.

8**Attach the Numbers and Hardware**

When the finish dries, you can install the address numbers. Then mount the solar lights to the openings in the Cap. Finally, attach a hanger. We used a “Hangman” system (see the Materials tab) that’s normally used to hang pictures. This two-piece hanger is super easy to install, and it’s made from aluminum so it will hold up fine outdoors. Following the manufacturer’s instructions, attach one side of the Hangman to the Hanging Cleat on your sign, and the other half to your house.
