



Pub Table

By **Kreg Tool**

Difficulty
Moderate

This pub table looks great, and will fit in your kitchen—or many other places—thanks to its compact size. Plus, the pub table is surprisingly simple to build from just a few boards you can get at any home center. It's the perfect companion to the Pub Chair plan you'll find here on BuildSomething.



Tools

Kreg Tools



Other Tools

Miter Saw

Square

Tape Measure

Drill (cordless)

Sander

Materials

Wood Products


- 2** Board , 2x2 , 96"
- 2** Board , 2x2 , 72"
- 2** Board , 1x4 , 72"
- 3** Board , 1x6 , 72"

Hardware & Supplies

- 67** 1 1/4" Coarse-thread Pocket Hole Screws
- 16** 2 1/2" Coarse-thread Pocket Hole Screws
- 16** 1 1/2" Flathead Wood Screws
- 1** Wood Glue

Cut List & Parts

- 4 Foot Rails , 1 1/2" X 1 1/2" X 29"
- 4 Legs , 1 1/2" X 1 1/2" X 42"
- 4 Aprons , 3/4" X 3 1/2" X 29"
- 4 Corner Blocks , 3/4" X 3 1/2" X 4"
- 6 Top Boards , 3/4" X 5 1/2" X 33"




Directions

1

Make the Foot Rails

Cut four Foot Rails to size from 2 x 2 boards, as shown in the cutting diagram. Then, with your pocket hole jig set for 1 1/2" material, drill pocket holes in these pieces where shown.



2


Cut the Legs to Size

Cut four Legs to size from a 2 x 2 board, as shown in the cutting diagram.

3

Make the Aprons


Cut four Aprons to size from 1 x 4 boards, as shown in the cutting diagram. Then, with your pocket hole jig set for 3/4" material, drill pocket holes where shown.



4

Start Base Assembly


Begin assembling the table base by creating two assemblies that each consist of two Legs, one Foot Rail, and an Apron. Position the Foot Rail between the Legs, as shown, and then attach it using 2 1/2" coarse-thread pocket hole screws. Then position the Apron and attach it to the Legs using 1 1/4" coarse-thread pocket hole screws. Repeat the process for the other assembly.



5

Complete the Base


Now you can bring these two assemblies together to complete the base. Attach the final two Foot Rails using 2 1/2" coarse-thread pocket hole screws. Then position the final two Aprons, and attach them to the Legs using 1 1/4" coarse-thread pocket hole screws.



6

Make Corner Blocks


Cut four Corner Blocks from 1 x 4 board, as shown in the cutting diagram. These will be used to reinforce the table base. Note that both ends of each Corner Block are beveled at 45°. Drill four 1/8" pilot holes through each Corner Block where shown.



7

Install the Corner Blocks


Attach the Corner Blocks to the Base using 1 1/2" flathead wood screws, as shown.



8

Make the Top Boards


Cut six Top Boards to length from 1 x 6 boards, as shown in the cutting diagram. With your pocket hole jig set for 3/4" material, drill pocket holes in five of the Top Boards, as shown. You don't need to drill pocket holes in the sixth Top Board.



9

Assemble the Top


Now you can assemble the top. Lay out the Top Boards as shown, and then attach them together using glue and 1 1/4" coarse-thread pocket hole screws. Once the glue is dry, sand the top smooth.



10

Attach the Top to the Base

With the top complete, you can attach it to the table base, as shown, using 1 1/4" coarse-thread pocket hole screws. Make sure that the top overhangs the table base equally on all sides.



11

Sand and Finish

Once your table is assembled, you can give everything a final sanding. Then apply the stain or finish of your choice.
