


# DIY Coat Rack

Difficulty

Easy

A DIY Modern Wall-Mounted Coat Rack. The sleek design is perfect for an entryway, bedroom, or mudroom!



# Tools

## Kreg Tools

Shelf Pin  
Jig with [Shelf Pin Jig with 1/4" Bit](#)  
1/4

Shelf Pin  
Jig with [Shelf Pin Jig with 1/4" Bit](#)  
1/4

## Other Tools

Miter Saw

Table Saw

Tape Measure

Drill (cordless)

Sander

# Materials

## Wood Products

**1** Board , 2x6 , 24"

## Hardware & Supplies

**20** "S-hooks"



# Cut List & Parts

1 Coat Rack , 2 3/4" X 1 1/4" X 2'

# Directions

---

1

## Cut 2x6 to length

Cut your 2x6 down to 24" in length






2

## Drill face holes


Using your shelf pin jig (set on the larger offset width), drill your holes along the face of the 2x6





**3****Cut 2x6 to width**

Cut the 2x6 down from 5 1/2" wide to 2 3/4" wide. You will want to ensure your holes are 1/2" from the bottom of the board (when determining the orientation of your cut).





**4****Drill Bottom Holes**

Using your shelf pin jig drill the holes along the bottom of the board (you will need to ensure the shelf pin jig is set to its smallest offset setting)





**5****Ream holes**

in order to get your S hooks to hook into the board you may need to slight ream the holes larger using your drill bit (make the holes slightly larger in the up/down direction).






6

### Sand and test fit

Sand your board and ensure all the holes allow the "S-Hooks" to fit properly.





**7****Stain / Finish board**

Once you are happy with the sanded finish you can stain/varnish or paint your hanger. We used an ebony by Rust-Oleum/Varathane stain on our hanger.

**8****Mount to wall**

We used key holes in the back of the board to mount it to the wall. But you can directly screw or use hangers from the hardware store to mount to the wall.