

DIY Modern Twin Bed

By **The Awesome Orange**

Difficulty
Moderate

This easy-to-make diy modern twin bed plan will bring some awesome style to your guest bedroom or kids bedroom.



DIY Modern Twin Bed



THE AWESOME ORANGE

Tools

Kreg Tools



Other Tools

Miter Saw

Tape Measure

Drill (cordless)

Sander

Materials

Wood Products

3 Board , 2x4 , 96"

7 Board , 2x2 , 96"

16 Bed Slat , 1x4 , 39"

Hardware & Supplies

36 2 1/2" Kreg Pocket Hole Screws


14 2" Spax Wood Screws

1 Set Of 4 - No Mortise Bed Frame Brackets

32 1 1/4" Spax Wood Screws

Cut List & Parts

- 9 Headboard Rail, Stiles & Footboard Bottom Stile , 1.5" X 1.5" X 39"
- 2 Headboard & Footboard Rails , 3.5" X 1.5" X 39"
- 2 Footboard Stiles , 1.5" X 1.5" X 14"
- 2 Bed Slat Supports , 1.5" X 1.5" X 74"
- 2 Side Rails , 3.5" X 1.5" X 76"




Directions

1

Cut to length

Cut all pieces to final lengths. I recommend using a stop block on your miter saw to create easy and accurate repeatable cuts.



2

Drill Pocket Holes

Drill two (2) 2 1/2" pocket holes on (7 of the 9) 39" L 2x2 boards & the two (2) 39"L 2x4 boards using your Kreg pocket hole jig.




3

Assemble Footboard

Assemble footboard. Pocket holes on the bottom 2x2 should be facing down and pocket holes on the 2x4 should be facing inside the bed frame to keep holes hidden.

Step 3




THE awesome orange

4

Assemble Headboard

Attach bottom rail to two side pieces first with pocket holes facing down. Then line up the footboard with the headboard and mark where middle 2x4 support should line up and then attach. Then attach top rail and each additional rail 1.5" apart from top with pocket holes facing the back.

Step 4




THE awesome orange

5

Attached Slat Supports

Attach slat supports to side rails using the 2" spax screws. I used a couple of bed slats to create the correct amount of spacing from the top.

Step 5




THE awesome ORANGE

6

Install Bed Frame Hardware

Hardware has a left and right side, so be sure to install proper bracket on each side using screws provided. Link to brackets I used in the Extras tab.

Step 6




THE awesome ORANGE

7

Assemble Bed

Attach rails to headboard and then attach to footboard.

Step 7




THE awesome ORANGE

8

Install Bed Slats

Lay out bed slats evenly and attach to slat support using 1 1/4" spax wood screws.

Step 8



THE awesome ORANGE

9

Visit theAwesomeOrange.com

Visit my website www.theAwesomeOrange.com to get more details and photos of this build and other awesome DIY projects!

THE awesome Orange

Build Loud, Build Wild
