


Easy Modern Bookshelf By Anika\'s DIY Life

Difficulty

Easy

Build a Modern bookshelf with an eclectic design perfect for decor and storage!





Page 1 of 6



Tools

Kreg Tools



Other Tools

Miter Saw

Sander

Workbench

Tape Measure

Materials

Wood Products

- 2 Board , 2x10 , 96"
- 1 Board , 2x6 , 72"

Hardware & Supplies

- 40 21/2" Pocket Hole Screws
- **3** Sand Paper Various Grits

Page 2 of 6



Cut List & Parts

- Long Side , 1 1/2" X 9 1/2" X 64"
- 1 Short Side , 1 1/2" X 9 1/2" X 51 1/2"
- **1** Bottom , 1 1/2" X 9 1/2" X 12"
- **5** Shelves , 1 1/2" X 9 1/2" X 8 3/4"
- **2** Backs, 1 1/2" X 5 1/2" X 26 1/2"

Page 3 of 6



Directions



Make Cuts and Pocket holes

Make all the cuts per the cut list.


Make pocket holes with Kreg Jig setup for 1 1/2" thick material.

Pocket holes are on in the shelves and bottom. Please review below steps for location of the pocket holes.



Build Side 1

Start by building side 1 of the shelf by attaching the bottom and shelves as shown in the drawing. Attach using 2 1/2" pocket hole screws and wood glue.




Page 4 of 6



Build Side 2

3

Attach the shelves to the long side per the diagram. Use 2 1/2" pocket hole screws and wood glue.



Page 5 of 6




4

Attach back

Lay down the back boards on the floor and align the shelves to them.

Then attach using 2 1/2" pocket hole screws and wood glue. Also, attach the bottom to the second side to complete the shelf.

Note - I used 2x6 boards for the backs. However, you can also use 1x6 boards if you want the shelf closer to the wall. In that case the pocket holes will be made at the 3/4" thickness setting and attached using 1 1/4" pocket hole screws.



See more information

5

For more details on this project, please see - https://www.anikasdiylife.com/modern-diy-bookshelf/ Video tutorial at - https://youtu.be/8ijBB8Ae5-o