

DIY Laundry Basket Shelves – Free Project Plan

Difficulty

Easy

This laundry basket shelf holds 6 basic laundry baskets. It is designed to be the height of a standard washer and dryer. The dimensions can easily be modified to fit any space. This is a basic build, with basic plywood and minimal tools. Perfect for a beginner.





Tools

Kreg Tools

- Accu-Cut™
[Accu-Cut™](#)
- Zinc Pocket-Hole Screws
[Zinc Pocket-Hole Screws](#)
- Kreg® Pocket-Hole Jig 720
[Kreg® Pocket-Hole Jig 720](#)
- Kreg® Pocket-Hole Jig 720
[Kreg® Pocket-Hole Jig 720](#)

Other Tools

- Circular Saw (cordless)
- Tape Measure
- Clamps
- Drill (cordless)
- Stapler
- Sander

Materials

Wood Products



- 2 Plywood , 3/4" Thick , Full Sheet
- 1 Plywood , 1/4" Thick , Half Sheet

Hardware & Supplies

- 50 1 1/4" Pocket Hole Screws (See Tools List)
- 10 Staples

Cut List & Parts

- 2 Top And Bottom , 3/4" X 24" X 37 1/4"
- 3 Vertical Supports , 3/4" X 24" X 37 1/2"
- 4 Shelves , 3/4" X 24" X 17 1/2"
- 1 Backing , 1/4" X 34 1/4" X 39"





Directions

1


Cut Plywood and Drill Pocket Holes

- Using 3/4" plywood, cut the following:
- 3- 24" x 37 1/2" with pocket holes on short sides (vertical pieces)
 - 2- 24" x 37 1/4" no pocket holes (top and bottom)
 - 4- 24" x 17 1/2" with pocket holes on long sides (shelves)
- Using 1/4" plywood backing, cut the following:
- 1- 37 1/4" x 39" (backing)



2**Build Box**


Using wood glue and 1 1/4" pocket hole screws, attach the 37 1/2" x 24" pieces to the 37 1/4" x 24" pieces.



3

Attach Middle Support


Using wood glue and 1 1/4" pocket hole screws, attach the middle vertical piece (37 1/2" x 24") to the center of the box. It should be about 17 1/2" on each side, but because materials vary, it's best to measure to find center.



4

Attach Shelves

Using wood glue and 1 1/4" pocket hole screws, attach the horizontal shelves, with the pocket holes on the underside. These shelves should be about 12" to 12 1/4" apart.



5

Finish

Sand, putty, and paint or stain your piece.

6**Add Backing**

Using staples, add the backing to the back of your shelf.

