

# Plywood Shelves for Closet

By **Jaime Costiglio**

Difficulty

Easy

Make that closet space function like it should with easy plywood shelving. You'll be kicking yourself for not installing these plywood shelves a long time ago. Customize to fit your closet space and you'll want to tackle all the closets in your home!





# Tools

## Kreg Tools



## Other Tools

- Circular Saw (cordless)
- Miter Saw
- Square
- Tape Measure
- Nail Gun

# Materials

## Wood Products

- 1** Plywood , 3/4" Thick , Full Sheet
- 2** Board , 1x2 , 96"
- 2** Board , 1x3 , 96"

## Hardware & Supplies

- 50** 2" Finish Nails
- 25** 1 1/4" Finish Nails



# Cut List & Parts

- 5 Shelves , 3/4" X 13" X 23"
- 10 Wall Cleats , 1 X 2 X 13"
- 5 Shelf Trim , 1 X 3 X 22 1/4"

# Directions

---

1

**Step 1**  
Cut 1x2 wall cleats to fit the depth of your closet space. Two cleats per shelf.

---

**2****Step 2**

Attach 1x2 cleats to wall using construction adhesive and 2" finish nails. Be sure to use a level and keep cleats in pairs.

---



3

### Step 3

Cut plywood shelves to fit. Measure depth of space x width of closet space. Place shelves into position on 1x2 cleats.

---





**4****Step 4**

Cut 1x3 front trim to fit each shelf front.

