

School Desk- small child size

Difficulty

Easy

This is a very simple build, built from off the shelf lumber. It can be built in just an afternoon with very basic tools. This desk is a child sized desk, meant for smaller children, about 8 years old and younger. The desk has an lid that opens for easy access to books, crayons, laptops, or tablets.





Tools

Kreg Tools



Other Tools

Circular Saw (corded)

Jigsaw

Miter Saw

Tape Measure

Drill (cordless)

Sander

Tape Measure

Materials

Wood Products


- 1 Board , 2x2 , 96"
- 1 Board , 1x4 , 96"
- 1 Board , 1x2 , 96"
- 1 Plywood , 1/2" Thick , Quarter Sheet

Hardware & Supplies

- 1 Piano Hinge (12")
- 50 1 1/4" Pocket Hole Screws
- 1 Wood Glue

Cut List & Parts

- 4 Legs , 22" (2x2)
- 2 Apron Sides , 16" (1x4)
- 2 Apron Front & Back , 20" (1x4)
- 3 Cubby Supports , 17.5" (1x2)
- 1 Cubby Bottom , 21 1/2" X 17 1/2" (1/2" Plywood)
- 1 Desk Top , 24" X 16" (1/2" Plywood)
- 1 Desk Top Back Portion , 24" X 3 1/2" (1/2" Plywood)
- 1 Desk Back , 22 1/2" (1/2)
- 2 Desk Sides , 4 1/2" (1/2)




2

Prepare Apron Boards

Cut TWO 20" 1x4 boards. Drill pocket holes in both ends of both boards.

Drill pocket holes on one side of one board.

Cut a notch out of the other board (see plans). This will create a space in order to open the lid of the desk later.



TheCreativeMom.com

3


Prepare Desk Back

Cut ONE 22 1/2" 1x2 board.

Cut TWO 4 1/2" 1x2 boards.

Cut a piece of 3/4" plywood, 3 1/2" x 22 1/2". Drill pocket holes in both ends of the plywood. Drill pocket holes in one side as well.

Using wood glue and 1 1/4" pocket hole screws, attach the plywood to the 1x2 pieces. (see plans)




TheCreativeMom.com

4

Attach Apron to Desk Back

Using wood glue and 1 1/4" pocket hole screws, attach the desk back to your 20" apron board you prepared earlier.




TheCreativeMom.com

5

Attach Back Apron


Using wood glue and 1 1/4" pocket hole screws, attach the piece you just built to the side pieces from step 1.



TheCreativeMom.com

6**Attach Front Apron**

Using wood glue and 1 1/4" pocket hole screws, attach the 20" 1x4 board with the notch cut from it. It should be flush with the front and tops of your 2x2 legs. The notch should be on the top of the board.




7

Attach Cubby Supports

Cut THREE 17 1/2" 1x2's. Drill pocket holes in both ends.


Using wood glue and 1 1/4" screws, attach the boards to the front and back apron. The bottoms of these boards should be flush with the bottoms of your 1x4 aprons.



8

Attach Cubby Bottom


Cut a piece of 1/2" plywood at 20" x 17 1/2". Using a jig saw, cut 3/4" x 3/4" notches from each corner. Lay this plywood on top of the 1x2 supports to create the bottom of your desk cubby.



9

Add Desk Lid

Cut a piece of 3/4" plywood at 16" x 24". Using a piano hinge, attach this piece of plywood to the piece you already attached on the back. Make sure the sides are flush with each other.



10

Finish

Stain or paint the desk. Seal with polyurethane.

