

X Arbor with Bench



By **My Love 2 Create**

Difficulty

Moderate

This X Arbor with Bench is the perfect accent to your garden or back yard escape. Not only is it beautiful and sturdy, it is the perfect spot to sit and relax. It can be stained or painted to fit your preference and would be great with potted plants on the side.





Tools

Kreg Tools



Other Tools

- Jigsaw
- Miter Saw
- Square
- Drill (cordless)
- Impact Driver
- Sander

Materials

Wood Products

- 10** Board , 2x4 , 96"
- 3** Board , 2x3 , 96"
- 3** Board , 2x2 , 96"
- 1** Board , 2x10 , 96"
- 2** Board , 2x6 , 72"


Hardware & Supplies

- 2002** 1/2" Pocket Hole Screws

Cut List & Parts

- 4 Legs , 1 1/2" X 3 1/2" X 80"
- 6 Rails , 1 1/2" X 3 1/2" X 16"
- 5 Seat Supports , 1 1/2" X 3 1/2" X 16"
- 7 Top Supports And Seat Aprons , 1 1/2" X 3 1/2" X 41"
- 4 Long X Pieces , 1 1/2" X 2 1/2" X 30.5
- 8 Short X Pieces , 1 1/2" X 2 1/2" X 15"
- 7 Top Rafters , 1 1/2" X 1 1/2" X 28"
- 2 Bench Seat Boards , 1 1/2" X 9 1/4" X 41"
- 2 Lower Rafters , 1 1/2" X 5 1/4" X 60"


my create



Directions

1**Build Sides**


Take the two 80" 2x4 legs and attach them together with the three 16" 2x4 rails as shown, using 1 1/2" pocket holes and 2 1/2" pocket hole screws.

*my2create*

2

Attach long x boards


Attach the two long 2x3 X pieces as shown in-between the rails on each side. An easy way to do this is to lay your 2x3 piece under the opening and trace where to cut the ends onto the board. I have provided the angles in the image for cutting on your miter saw. Drill 1 1/2" pocket holes and attach with 2 1/2" pocket hole screws on each angled cut and attach them to the legs and rails.



3

Attach small x boards

Attach small 2x3 x boards to complete the x pattern using the images shown. Drill 1 1/2" pocket holes and attach with 2 1/2" pocket hole screws.




my create

4

Attach top supports and seat aprons


Connect the two sides together with the 41" 2x4 top support and seat apron boards with 1 1/2" pocket holes and 2 1/2" pocket hole screws.



5

Add seat supports


Add the 16" 2x4 seat supports as shown with 1 1/2" pocket holes and with 2 1/2" pocket hole screws.



6

Add Seat


Add 41" 2x10 seat boards to seat support with 2 1/2 screws.



7

Add Seat back boards


Add the 41" 2x4 seat back boards as shown with 1 1/2" pocket holes and with 2 1/2" pocket hole screws.



8

Attach 2x6 Rafters

Attach bottom 60" 2x6 rafters to legs and top support boards with 2 1/2" screws.



9

Add top rafters

Attach top 28" 2x2 top rafters as shown. Fill pocket holes and screw holes and finish as desired.

