

DIY Plans to Build a Norham Coffee Table

By **Designs by Studio C**

Difficulty
Moderate

This table is the ultimate in storage with four drawers (two on each side), a huge shelf, and a large top. Edge banding will be applied to the exposed edges of the plywood prior to assembly.

THE NORHAM COFFEE TABLE



Tools

Kreg Tools



[Kreg® Pocket-Hole Jig 720](#)



[Zinc Pocket-Hole Screws](#)



[Kreg® Pocket-Hole Jig 720](#)

Other Tools

- Jigsaw
- Miter Saw
- Table Saw
- Tape Measure
- Nail Gun
- Sander
- Air Compressor

Materials

Wood Products

- 1** Board , 1x2 , 72"
- 2** Board , 1x3 , 96"
- 3** Board , 1x4 , 96"
- 1** Board , 2x2 , 72"
- 1** Plywood , 3/4" Thick , Half Sheet
- 1** Plywood , 3/4" Thick , Full Sheet

Hardware & Supplies

- 4** 12" Drawer Slide Sets
- 4** Drawer Pulls
- 100** 1-1/4" Brad Nails
- 100** 1-1/4" Pocket Hole Screws (See Tools List)
- 25** 1-1/4" Screws
- 1** Roll Of Edge Banding
- 1** Wood Glue
- 1** Sandpaper - 100, 150, 220 Grits
- 1** Primer & Paint Or Stain & Sealer


Cut List & Parts

- 4** Legs , 2x2 At 19-1/4"
- 2** Bottom & Shelf , 3/4" Plywood At 28" X 48"
- 2** Sides , 3/4" Plywood At 4-7/8" X 25"
- 2** Drawer Spacers , 1x2 At 25"
- 1** Divider , 3/4" Plywood At 4-7/8" X 28"
- 2** Upper Aprons , 1x3 At 25"
- 2** Upper Aprons , 1x3 At 45"
- 2** Center Supports , 1x3 At 26"
- 1** Top , 3/4" Plywood At 29" X 49"
- 4** Drawer Box Bottoms , 3/4" Plywood At 10-1/2" X 19-5/8"
- 8** Drawer Box Sides , 1x4 At 10-1/2"
- 8** Drawer Box Front & Back , 1x4 At 10-1/2"
- 4** Drawer Fronts , 3/4" Plywood At 4-5/8" X 21-7/8"


Directions

1**Step One**

Cut the pieces for the legs and the bottom. Cut the notches in the bottom using a jigsaw. With the pocket hole jig set for $\frac{3}{4}$ " material, drill pocket holes in each notch as shown.

**2****Step Two**


Position the legs in the notches as shown then secure using glue and 1-1/4" pocket hole screws.



3

Step Three


Cut the pieces for the sides and drill pocket holes in one long edge of each piece. Secure the sides to the bottom between the legs using glue and 1-1/4" pocket hole screws. The outside face of the sides will be flush with the outside face of the legs.



4

Step Four


Cut the pieces for the drawer spacers. Position the spacers between the legs so they rest on the bottom and secure in place using glue and countersunk 1-1/4" screws.



5

Step Five


Cut the piece for the drawer divider and drill pocket holes along one long edge. Secure to the bottom as shown using glue and 1-1/4" pocket hole screws.



6

Step Six


Cut the piece for the shelf and cut the notches using a jigsaw. Spread glue on the top edge of the sides and the divider, then position the shelf on top.



7

Step Seven


Secure the shelf using glue and 1-1/4" brad nails through the shelf into the sides and divider.



8

Step Eight


Cut the pieces for the upper aprons and drill pocket holes in each end. Spread glue on the ends of each piece and position the pieces as shown locating them 1/4" back from the outside face of each leg. Secure using 1-1/4" pocket hole screws.



9

Step Nine


Cut the pieces for the center supports and drill pocket holes in the ends of each piece. Secure to the longer aprons using glue and 1-1/4" pocket hole screws.



10

Step Ten


Cut the piece for the top. Spread glue on the top edges of the aprons and the supports. Position the top so that it overhangs by 1/2" on each side. Secure using glue and 1-1/4" brad nails through the top into the aprons, legs, and supports.



11

Step Eleven

Cut the pieces for the drawer boxes. Drill pocket holes in all four edges of the bottom pieces as well as each end of the side pieces. Secure the sides to the bottom using glue and 1-1/4" pocket hole screws.




12

Step Twelve

Secure the front and back pieces using glue and 1-1/4" pocket hole screws through the bottom pieces, as well as the side pieces.

Install the drawer slides in the cabinet according to the manufacturer's installation instructions locating them 3/4" back from the outside faces of the legs. Install the other half of the drawer slides on the bottom of the drawer boxes. Make any necessary adjustments.



13

Step Thirteen

Cut the pieces for the drawer fronts. Mark the position for the drawer pulls and drill the holes. Shim the drawer front in the opening – there will be a 1/8" gap around all sides – then drive screws through the holes for the drawer pulls into the drawer box. Open the drawer, and secure the drawer front using countersunk 1-1/4" screws from the inside. Remove the screws from the holes for the drawer pull then finish drilling the holes. Install the drawer pull.

