TABLE OF CONTENTS
DESCRIPTION
COVER PAGE
OVERALL DIMENSIONS
CABINET PARTS
CABINET ASSEMBLY
BACK PANEL & POWER SUPPLY SUPPORT
BASE ASSEMBLY
DRAWER BOXES
INSTALL DRAWERS
DESK TOP
HIDDEN POWER SUPPLY ACCESS DETAILS
SHEET GOODS LAYOUT, CABINET PARTS
SHEET GOODS LAYOUT, DRAWER BOX PARTS
POWER SUPPLY 1:1 TEMPLATE (SUPPORT & HINGE CUT OUT)
POWER SUPPLY 1:1 TEMPLATE (TOP CUT OUT)






mike@woodshopmike.com


www.woodshopmike.com mike@woodshopmike.com

# HOME OFFICE DESK WITH HIDDEN **POWER SUPPLY**

PROJECT NAME: HOME OFFICE DESK WITH HIDDEN POWER SUPPLY DRAWING NAME: COVER SHEET	DESCRIPTION	INITIAL RELEASE				•
ME: POV	ВУ	МР				ပု
ING NAM	DATE	10-28-				Mike, LI
DRAW	REV	00				on of oodshop
Woodshop Maffiliates are damages that or properties creation or uplans. The construction acknowledge fabricator as proper const the project the	not respond at may consider involved ase of this use of the of this present the sume all truction a	onsibome to during sproject at you liabiling se	le for period per tente de la period peri	erso the or s and s the for use	ns d	uction of this document without the written authorization of nop Mike, LLC is strictly prohibited Copyright 2021,Woods
						ion of thi Mike, L
SHT. NO:	1					Reproduct Woodshop


MATERIALS		
ITEM	QTY	T W
3/4" PLYWOOD, 4'X8'	2	at da
1/2" PLYWOOD, 4'X8'	1	
1/4" PLYWOOD, 4'X8'	1	CI
HARDWOOD OF CHOICE 4/4	~20bf	pl
20" UNDERMOUNT DRAWER SLIDES	6 SETS	C
1-1/4" POCKET HOLE SCREW	<100	a
2-1/2" POCKET HOLE SCREW	8	fa
1" MICRO POCKET HOLE SCREW	<100	р
1" FLAT HEAD SCREWS	20	th
GLUE	32oz	
GENERAL FINISHES, HIGH PERFORMANCE TOP COAT	1 qt	
GENERAL FINISHES, STAIN BLOCKER PRIMER	1 qt	
GENERAL FINISHES, ENDURO WHITE POLY	1 qt	
DRAWER PULLS	6	SH
SMALL HINGES	2	
POWER STRIP	1	






QTY's TO BUILD 2 CABINETS


POCKET HOLES TO BE DRILLED ALONG EDGES AS NOTED.
POCKET HOLES TO BE 2" FROM EDGE (WHERE POSSIBLE) & EVENLY SPACED 6"-8" IN BETWEEN EACH EDGE. THERE SHOULD BE A MINIMUM OF 2 POCKET HOLES IN EACH PIECE.








QTY: 4

MTR'L: 3/4" PLY










MTR'L: 3/4" PLY



MAKE 12" AND 20-3/4" SPACERS. THIS WILL MAKE INSTALLING STRETCHERS FASTER.

PROJECT NAME: HOME OFFICE DESK WITH HIDDEN POWER SUPPLY DRAWING NAME: CABINET PARTS BY MP Reproduction of this document without the written authorization of Woodshop Mike, LLC is strictly prohibited Copyright 2021, Woodshop Mike, LLC DATE REV 00 Woodshop Mike, LLC and it's affiliates are not responsible for any

mike@woodshopmike.com

damages that may come to persons or properties involved during the creation or use of this project or plans. The use of these plans and construction of this projects is acknowledgement that you as the fabricator assume all liability for proper construction and safe use of the project through all stages.

SHT. NO:


**BUILD 2 OF THESE CABINETS** 

CONSTRUCT CABINET WITH 1-1/4" POCKET HOLE SCREWS.

EDGEBAND OR PUTTY FRONT EDGE OF PIECES FOR A SMOOTH SURFACE PRIOR TO PAINTING.




SECURE PART 1 & 2 WITH POCKET HOLES. POCKET HOLES ON PART 2 TO FACE DOWN.




# STEP 2

SECURE PART 2 TO PART 1 WITH POCKET HOLES. **POCKET HOLES ON PART** 2 TO FACE UP.



# STEP 3


**SECURE PART 1 AS SHOWN** WITH POCKET HOLES.



# STEP 4

ADD 2 OF PART 3 WITH POCKET HOLES. POCKET HOLES TO FACE DOWN.


USING A PAIR OF 20-3/4" SPACERS WILL MAKE **INSTALLATION OF PART 3** EASIER.



# STEP 5

ADD 2 OF PART 3 WITH POCKET HOLES. POCKET HOLES TO FACE DOWN.

**USING A PAIR OF 12"** SPACERS WILL MAKE **INSTALLATION OF PART 3** EASIER.



### STEP 6

ADD 2 OF PART 4 WITH GLUE, BRADS, OR SCREWS AS SHOWN.

**CENTERED ON CABINET TOP** AND FLUSH WITH BACK OF CABINET.

**INSTALL DRAWER SLIDES** PER MFG INSTRUCTIONS.






mike@woodshopmike.com

PROJECT NAME: HOME OFFICE DESK WITH HIDDEN POWER SUPPLY	DRAWING NAME: CABINET ASSEMBLY	DESCRIPTION	INITIAL RELEASE				•
ME: PO	ME: CAB	ВХ	МР				ပု
CT NAN	ING NAN	DATE	10-28-				Mike, LI
PROJE	DRAW	REV	00				on of sodshop
affili dam or p crea plan cons ackr fabr	odshop Mates are lages that roperties tion or u s. The ustruction nowledge icator as per const project th	not resp at may co involved se of this use of the of this prement the sume all ruction a	onsibome to during sproject at you liabiling and se	le for period per	erso the or s an the	ns d	f this document without the written authorizat e, LLC is strictly prohibited Copyright 2021,W
							ction o
SHT.	NO:	4	ļ				Reprodu Woodsh


POCKET HOLES TO BE DRILLED ALONG EDGES AS NOTED. POCKET HOLES TO BE 2" FROM EDGE (WHERE POSSIBLE) & EVENLY SPACED 6"-8" IN BETWEEN EACH EDGE. THERE SHOULD BE A MINIMUM OF 2 POCKET HOLES IN EACH PIECE.

ASSEMBLE BASE WITH 1-1/4" POCKET HOLE SCREWS.




# PART 5

QTY: 1 MTR'L: 3/4" PLY




# PART 6

QTY: 1 MTR'L: 3/4" PLY (OPTIONAL)




### PART 7

QTY: 2 MTR'L: 3/4" PLY (OPTIONAL)



# ASSEMBLE POWER STRIP SHELF


(OPTIONAL)



### **BACK ISO VIEW**

SCREW PARTS 6 & 7 ON BACK OF PART 5 AS SHOWN. WHERE POSSIBLE, POCKET HOLES TO FACE DOWN SO THEY AREN'T VISIBLE FROM TOP OF DESK.

CENTER POWER STRIP SHELF ON BACK OF PART 5 2" BELOW TOP EDGE.



SIDE VIEW




mike@woodshopmike.com


PROJECT NAME: HOME OFFICE DESK WITH HIDDEN POWER SUPPLY DRAWING NAME: BACK PANEL & POWER SUPPLY SUPPORT	DESCRIPTION	INITIAL RELEASE				<b>4</b>
ME: HO	ВУ	МР				ပု
PROJECT NAME: DRAWING NAME:	DATE	10-28-				Mike, LI
PROJE	REV	00				on of sodshop
Woodshop Mike affiliates are not damages that m or properties invorceation or use plans. The use construction of tacknowledgeme fabricator assun proper construct the project through	responday controlled this point the all tion a	onsilome didures project proje	ble f to pe ing f ject blans ts is u as lity f afe	or a erso the or s an s the for use	d d	his document without the written authorizati LLC is strictly prohibited Copyright 2021,W
						on of thi Mike, L
SHT. NO:	5	5				Reproducti Woodshop

SHT. NO:

ASSEMBLE BASE WITH 1-1/4" POCKET HOLE SCREWS.

ATTACH POWER SUPPLY CENTERED ON POWER SUPPLY SHELF.







mike@woodshopmike.com

Moodshop M affiliates are r damages that or properties	not resp may co	onsil	ole f to p	for a	•	ten authorization of Mike, LLC
creation or us plans. The us construction or	se of the	ese p	lan	s an	ıd	ut the wi
acknowledge fabricator ass	ume all	liabi	lity 1	for		t witho
proper constr the project the					of	his document withor LLC is strictly prohit
						of this like, LL(
HT. NO:						duction shop M
	6	)				Repro

_

SHT. NO:

# DRAWER BOX ASSEMBLY


DRILL 2 MICRO POCKET HOLES (FOR TOP DRAWERS) AND 3 MICRO POCKET HOLES (FOR MIDDLE & BOTTOM DRAWERS) IN EACH END OF DRAWER BOX FRONTS/BACKS (PARTS 8-11).

EXACT PLACEMENT OF HOLES IS NOT CRITICAL, SPACE HOLES ROUGHLY 1/2" FROM EDGE.

\*\*DO NOT DRILL BELOW GROOVE FOR THE DRAWER BOTTOM\*\*


ASSEMBLE DRAWER BOXES AS SHOWN BELOW. CLAMP BOX TOGETHER AND USE 1" PAN HEAD POCKET HOLE SCREWS TO SECURE


\*IF USING SLIDES FROM ITEM LIST, DRILL HOLE IN BACK OF DRAWERS ONCE BOXES ARE ASSEMBLED PER MFG INSTRUCTIONS





MTR'L: 1/2" PLY


2 3/4"












**NOTCH FOR DRAWER SLIDES** (ONLY IF USING SAME DRAWER SLIDE)

**PART 11** 


QTY: 4

MTR'L: 1/2" PLY


6"



**GROOVE FOR** DRAWER BOTTOM (PART 14)



13 1/2"



mike@woodshopmike.com

Woodshop Mike, LLC and it's affiliates are not responsible for any damages that may come to persons or properties involved during the creation or use of this project or plans. The use of these plans and construction of this projects is acknowledgement that you as the fabricator assume all liability for proper construction and safe use of the project through all stages.

SHT. NO:


MTR'L: 1/2" PLY

MTR'L: 1/2" PLY

**PART 14** QTY: 6 MTR'L: 1/4" PLY

# STEP 1

SCREW DRAWER BOX SIDES (PARTS 12 OR 13) TO DRAWER BOX FRONT (PARTS 8 OR 10).




**PART 12** 

QTY: 4

MTR'L: 1/2" PLY

# STEP 2


SLIDE DRAWER BOTTOM INTO PLACE (PART 14).



### STEP 3


SCREW DRAWER BACK (PARTS 19 OR 11) TO DRAWER BOX SIDES (PARTS 12 OR 13).

21 1/2"





SET DRAWER BOXES ON UNDERMOUNT SLIDES AND FULLY SEAT INTO LATCHING MECHANISM.




# STEP 2

CENTER DRAWER FRONTS IN CABINET OPENINGS AND SECURE TO BOX WITH 1" SCREWS FROM INSIDE OF DRAWER.

CENTER AND ATTACH DRAWER PULLS.


REPEAT FOR OTHER CABINET.





mike@woodshopmike.com

PROJECT NAME: HOME OFFICE DESK WITH HIDDEN POWER SUPPLY DRAWING NAME: INSTALL DRAWERS	DESCRIPTION	INITIAL RELEASE				•
I	ВУ	MP				ပု
PROJECT NAME: DRAWING NAME:	DATE	10-28-				Mike, LL
PROJE	REV	00				on of sodshop
Woodshop Mike affiliates are not damages that m or properties invocreation or use plans. The use construction of tacknowledgeme fabricator assumproper construct the project throught	respondy colvertof this of the ent the	onsibome to during project at you liabil	o poing the control of the control o	erso the or s an the or use	d d	f this document without the written authoriza e, LLC is strictly prohibited Copyright 2021,W
						op Mik
SHT. NO:	8	3				Reprodu





DETAILS FOR OPTIONAL CUTOUT TO ACCESS HIDDEN POWER SUPPLY.

SECTION BB-BB SHOWS VARIOUS DEPTHS THAT CUTOUT SHOULD BE CUT TO.

I USED TWO TEMPLATES TO CUT THIS FEATURE WITH MY ROUTER. 1:1 SHEETS OF THESE TEMPLATES ARE AT THE END OF PLANS.

\*BASED ON HINGE USED, ADJUST AS NEEDED.










mike@woodshopmike.com


PROJECT NAME: HOME OFFICE DESK WITH HIDDEN POWER SUPPLY DRAWING NAME: HIDDEN POWER SUPPLY DETAILS	DESCRIPTION	INITIAL RELEASE			•
AE: HOM	ВУ	MP			ر اد
ECT NAM	DATE	10-28- 2022			Mike, LI
PROJE	REV	00			on of oodshop
Woodshop Maffiliates are damages that or properties creation or uplans. The uplans. The uplans construction acknowledge fabricator as proper constitute project the	not resp at may co involved se of this use of the of this prement the sume all ruction a	onsibome to during sprojectom tyou liabilind sa	le for a persong the ect or ans an s is u as the ty for fe use	ons ad	ction of this document without the written authorization of op Mike, LLC is strictly prohibited Copyright 2021,Woods
					on of thi Mike, L
SHT. NO:	1	0			Reproducti Woodshop








**BOTTOM VIEW** 





**BOTTOM VIEW** 

