


Rolling Drill Press Cart: With Bonus Storage

By **Lazy Guy DIY**

Difficulty
Moderate

Rolling Drill Press Cart with additional storage for power sanders and pull out forstner bit storage.





Tools

Kreg Tools



[Kreg® Pocket-Hole Jig 720](#)

Other Tools

Miter Saw

Tape Measure

Clamps

Drill Press

Impact Driver

Nail Gun

Air Compressor

Materials

Wood Products

1 Board , 1x2 , 72"

2 Board , 2x4 , 96"

1 Plywood , 3/4" Thick , Half Sheet

Hardware & Supplies

4 Caster

Cut List & Parts


- 4 Base Legs , 2x4" X 31.50"
- 2 Plywood Top & Bottom , 16" X 11"
- 2 Shelving Sides , 24.50" X 12.50"
- 2 Shelves , 12.50" X 6.50"
- 1 Top Shelf , 12.50" X 8"
- 1 Forstner Shelf , 16" X 8"
- 2 Shelf Slide , 1x2" X 16"
- 2 Top Shelf Side , 1x2" X 17.50
- 2 Top Shelf Front/Back , 1x2" X 11"

Directions

1

Building The Base


Cut all four 2x4's to length at 31.50". Pre-drill pocket holes for 3/4" depth into the ends of all four. Cut 3/4" plywood to length at 11" x 16". Attach 2x4's to base using 1 1/4" pocket screws.



2

Attach Top


Attach your 11"x16" plywood to the base using 1-1/4" pocket screws. You can also attach your casters to what side you deem is the bottom at this point.



3**Building the Tray**

Using your 17.5" and 11" pieces of 1x2" frame around the top shelf using wood glue and brad nails to create a tray.

Cut side aprons out of 1x2"
17.50" for sides
11" for front and back.
Attach with wood glue
and brad nails.




www.LazyGuyDIY.com

4

Building the Shelving Insert

Cut the side pieces (2) to 24.50" x 12.50" and the shelves to (2) 12.50" x 6.50". Cut the top shelf to 12.50" x 8". Before assembling, add 3/4" depth pocket holes to attach the shelving to the base. Assemble shelves allowing for 8" of spacing between the bottom two shelves.



5

Attach Shelving to Base

Attach to the base using 1-1/4" pocket screws.



6

Adding Forstner Bit Storage

Cut plywood to length 8"x16" for Forstner bit storage. Using your soon to be attached drill press, cut 1/4" pilot holes into board for Forstner bit storage. Do not cut holes all the way through board or the bits will slide through and cause issues with your drawer sliding.

Cut 1x2" (2) to 16". Using a spacer (like cardboard) place under Forstner bit shelf and then attach 1x2" shelving slides. When the spacer is removed, the Forstner drawer will easily slide out.

