

2×4 Barstools

By Sawdust Sisters


Difficulty

Easy

DIY Barstools Using only 2x4s









Tools

Kreg Tools

Wood

Project Wood Project Clamp - 6"

Clamp -

6

Kreg®

Pocket- Kreg® Pocket-Hole Jig 720

Hole Jig 720

Other Tools

Miter Saw

Tape Measure

Drill (cordless)

Sander

Materials

Wood Products

2 Board , 2x4 , 96"

Hardware & Supplies

28 Pocket Screws



Cut List & Parts


1 See Images ---> , See Images--->

Seat: 3 pieces at 12"

Legs: 4 pieces at 25" with ends beveled at 10 degrees. Ends are parallel.

Large crossbars: 2 pieces at 14 1/4". Ends are mitered at 10 degrees. Ends are not parallel.

Small crossbars: 2 pieces at 4 1/4"





Directions




Build the Seat

Using your Kreg Jig drill pocket holes

in the 3 pieces that make up the seat. Drill your pocket holes 2-3 inches away from the ends and attach with pocket screws. You will want to leave room to attach the legs later.









Cut and Attach the Legs

The cuts you make for the legs should be beveled

at 10 degrees and parallel. Drill pocket holes on one side (on the longer end of the bevel). This is the side that will attach to the seat. Attach with pocket screws.

Use wood glue on the seams. Attach the legs flush to the outside of the seat.



Drill pocket holes on the longer end of the bevel








Cut and Attach the Large Crossbars

The 2 crossbars are mitered at 10 degrees, not parallel. After making the cuts, drill pocket holes on both ends and attach the crossbars to the legs. I attached them

5 inches from the bottom and flush with the outside.










Cut and Attach the Small Crossbars

Cut the small cross bars. Drill two pocket holes in opposite directions, then attach them with 2 1/2 " pocket screws.











5

Paint and Enjoy!

For more ideas and free plans visit sawdustsisters.com

