


# Children's Workbench

Difficulty

Easy

Project No. 12 of our "12 Projects Of Christmas" series wraps up with this easy to build "BIG" kid workbench. Great for beginner wood workers from age 6 to 12 who want to give mom and dad a helping hand in the workshop!





# Tools

## Kreg Tools

 [Wood Project Clamp - 6"](#)

 [Kreg® Pocket-Hole Jig 720](#)

 [Mobile Project Center](#)

## Other Tools

Circular Saw (corded)

Miter Saw

Square

Tape Measure

Drill (cordless)

Impact Driver

Nail Gun

# Materials

## Wood Products

4 Board , 1x2 , 96"

4 Board , 1x6 , 96"

4 Board , 1x4 , 96"

## Hardware & Supplies

1 Kreg Screws 1 1/4 Inch

1 Brad Nails 1 1/2 Inch

# Cut List & Parts

- 3**    Workbench Top , 1" X 6" X 36"
- 2**    Back Legs , 1" X 4" X 29-1/4"
- 2**    Front Legs , 1" X 4" X 29-5/8" (Long Point To Short Point) Ends Cut At 9 Degrees And 10 Degrees Parallel
- 1**    Back Leg Brace , 1" X 4" X 30-1/4"
- 2**    Side Leg Braces , (See Step 12 For Instructions)
- 2**    Pegboard Braces , 1" X 4" X 23-1/4"
- 2**    Long Trim , 1" X 2" X 32-3/16"
- 2**    Short Trim , 1" X 2" X 21-1/4"
- 1**    Pegboard , 32" X 24"



# Directions

---

1

**Step 1:**

Cut (3) 1" x 6" boards at 36" long




2

**Step 2:**

Drill (3) pocket holes into one side of (2) of your 1" x 6" x 36" boards using your Kreg Jig K5


---





**3****Step 3:**

Lay all (3) of your 1" x 6" x 36" boards together on a flat surface, placing the (1) board without pocket holes in the middle. Then attach together using your Kreg screws.





**4****Step 4:**

Next you will cut the back legs for your workbench: you will cut (2) 1" x 4" boards, cut to 29-1/4" in length.




5

**Step 5:**

Now you will adjust your miter saw to cut a 10 degree cut (as shown).

---





# 6

## Step 6:

You will proceed to cut 10 degree cuts at one end of (2) full length boards. After your end angles are cut, you will measure up each board (long point to short point) to 29-5/8", mark then cut a 9 degree angle, parallel to your 10 degree angle.

---



**7****Step 7:**

Drill (2) pocket holes into one end of each of your (4) 1" x 4" boards that you just cut to length.






**8****Step 8:**

After all pocket holes are drilled, you are ready to attach all (4) legs to the bottom side of your workbench counter. Place each front leg (your 2 legs that are angled on both ends - 9 degree cut end will be placed on the wood, 10 degree cut end will rest on ground once assembled) 2" in from the side edge and 2" in from the front edge then attach using your Kreg screws.

---



9

**Step 9:**

Place each back leg 2" in from the side edge and then flush with the back side. Attach using your Kreg screws.

---





**10****Step 10:**

Cut the back brace for your workbench using a 1" x 4" board cut to 30-1/4"



**11****Step 11:**

Drill (2) pocket holes into each end of your 1" x 4" x 30-1/4" board, then position the bottom of your board, 11-1/4" up from the bottom of your back legs and centered in the width of the back legs. Then screw into place using your Kreg screws.






## 12

### Step 12:

There are probably many ways to do this next step, and I am sure this way is not the one master carpenters would tell you to do... but this is the method we found the easiest when it came to cutting our next piece of wood:

Now that your legs are assembled, you will need to cut a supporting brace to attach the sides of them. For this, we took another 1" x 4" board and placed it on the back side of the legs, lined up flush with the back support brace that you just installed. Once the board is level, mark out the lines where you need to cut. Repeat this process for both sides.




13

**Step 13:**


Drill (2) pocket holes into each end of your side braces.

---



**14****Step 14:**

Attach the side braces 11-1/4" up from the bottom of each leg and flush with the back brace. Make sure side brace is level then attach using 1-1/4" Kreg screws.






**15****Step 15:**

The bottom half of your workbench is now fully assembled, next it is time to work on the top - Start by cutting (2) 1" x 4" boards to 23-1/4". These will be the braces that attach to the top of your workbench counter to hold the pegboard in place. After your boards are cut, drill (2) pocket holes into (1) end of each board then attach to the top of your work surface, placing the boards flush with the back and 2" in from each side.

---




16

**Step 16:**


Next, it's time to cut the pegboard. Using a circular saw, cut your pegboard down to 32" x 24"

---



**17****Step 17:**


Attach the pegboard to your braces using 3/4" screws





**18****Step 18:**

Now for the last pieces... stay with me, we are almost done! Take your 1" x 2" trim boards and cut (2) to 32-3/16" and (2) to 21-1/4". Then attach to the edges of your pegboard using 1-1/2" brad nails.



**19****Step 19:**

Stain it. Use your stain of choice, in our case we went with weathered oak (our favorite).



# 20

## Step 20:

You did it! Give yourself a pat on the back, and if you have been following this build series, we THANK YOU for following along all of the way to the end! We hope that you have enjoyed these projects and have been inspired to build your own for the ones in your life that you love. There is no better gift than one that came from your own two hands.

---

