

Double Compost Bins

By **Rogue Engineer**

Difficulty

Easy

Composting is one of the greenest things you can do. Not only are you diverting garbage from the landfill but you are creating amazing soil. Since the composting process does take time this double compost bin allows multiple batches. The lid makes for easy disposal and the doors for easy removal



Tools

Kreg Tools



Other Tools

- Jigsaw
- Miter Saw
- Tape Measure
- Drill (cordless)
- Hammer
- Impact Driver
- Sander

Materials

Wood Products


- 3** Cedar , 4x4 , 96"
- 11** Cedar , 2x4 , 96"
- 5** Cedar , 5/4x6 , 120"

Hardware & Supplies

- 7** Gate Hinges
- 2** Gate Latches
- 1** 3' X 25' Poultry Wire
- 1** Roofing Material
- 24** 1" Roofing Screws
- 125** 2-1/2" Kreg HD Pocket Screws
- 150** 3/4" Poultry Nails

Cut List & Parts

1 See , Cut List



Directions


1

Assemble Frame

Drill the Kreg HD pocket holes and assemble the frame using 2-1/2" Kreg HD pocket screws.

Download printable PDF in extras tab.

Step 1: Assemble Frame




2

Assemble Doors

Drill Kreg HD pocket holes and assemble with 2-1/2" Kreg HD pocket screws.

Step 2: Assemble Doors




Drill Kreg HD pocket holes and assemble
with **2-1/2" Kreg HD pocket screws**.

3**Assemble Lid**

Drill Kreg HD pocket holes and assemble with 2-1/2" Kreg HD pocket screws.

Step 3: Assemble Lid



Drill Kreg HD pocket holes and
assemble with 2-1/2" Kreg HD pocket screws.

4


Final Assembly

Attach roofing to lid using 1" roofing screws.

Cut poultry wire to size and attach to inside of frame and doors with 3/4" poultry staples.

Shim doors for even gaps and install doors and lid with hinges and included hardware.

Step 4: Final Assembly



Attach roofing to **lid** using
1" roofing screws.

Cut poultry wire to size
and attach to inside of
frame and **doors** with
3/4" poultry staples.

Shim **doors** for even gaps
and install **doors** and **lid**
with hinges and included
hardware.